











## Dash & Dot: Compatibility

# Apple iOS Devices

Type	Model	OS	 Wonder	 Go	 Blockly	 Path	 Xylo
Tablets	<ul style="list-style-type: none"> <li>&gt; iPad 3, 4</li> <li>&gt; iPad Air 1,2</li> <li>&gt; iPad Mini 1, 2, 3</li> </ul>	8.1+	✓	✓	✓	✓	✓
Phones	<ul style="list-style-type: none"> <li>&gt; iPhone 5, 5c, 5s</li> <li>&gt; iPhone 6, 6 Plus</li> <li>&gt; iPhone 6s, 6s Plus</li> <li>&gt; iPod Touch 5</li> </ul>	8.1+	✓	✓		✓	✓

## Dash & Dot: Compatibility

# Android Devices

Type	Model	OS	 Wonder	 Go	 Blockly	 Path	 Xylo
Tablets	<ul style="list-style-type: none"> <li>&gt; Nexus 7 (2013)*</li> <li>&gt; Nexus 9</li> <li>&gt; Galaxy Note 10.1</li> <li>&gt; Galaxy Note Pro 12.2</li> <li>&gt; Galaxy Tab 3, 8, 10.1</li> <li>&gt; Galaxy Tab 4.7, 8, 10.1</li> <li>&gt; Galaxy Tab Pro 8.4</li> <li>&gt; Galaxy Tab S 8.4, 10.5</li> <li>&gt; Nabi 2S</li> <li>&gt; Nabi DreamTab**</li> </ul>	4.4.2+	✓	✓	✓	✓	✓
	Phones	> Galaxy S4, S5	4.4.2+	✓	✓		✓

\* The Nexus 7 (2013) can only connect to one robot at a time.

\*\* Nabi DreamTab does not support Wonder yet